CROSLEY

CR1205A

Tablet Jukebox



Instruction Manual

910-119040-0010-200

www.crosleyradio.com

Troubleshooting

There's no sound

1 Make sure jukebox is plugged in, power switch is on and jukebox. is not in standby mode."

2 Make sure the mute function is turned off.

3 Make sure SPEAKER INT.EXT.MIX switch on back of jukebox is on " INT. " or " MIX. ". (if you are using external speakers, it should be on " EXT. ")

4 Check that the volume is turned up by pressing vol.+ button on remote.

CD does not play

1 Check and make sure CD is inserted correctly.

2 Check and make sure the CD is clean.

3 Make sure jukebox is in CD mode.

Remote not working

1 Ensure batteries in remote are working properly and fully charged

2 Make sure the remote is pointed towards the remote sensor and no obstacles are blocking the signal

IMPORTANT SAFETY INSTRUCTION

PLEASE READ CAREFULLY ALL THE FOLLOWING IMPORTANT SAFEGUARDS THAT ARE APPLICABLE TO YOUR EQUIPMENT

1. Read Instructions - All the safety and operating instructions should be read before the product is operated.
2. Retain instructions - The safety and operating instructions should be retained for future reference.
3. Heed Warnings - All warnings on the product and in the operating Instructions should be adhered to.
4. Follow Instructions - All operating and use instructions should be followed.
5. Cleaning - Unplug this product from the wall outlet before cleaning. Do not use liquid cleaners or aerosol cleaners.Use a damp cloth for cleaning.
6. Attachments - Do not use attachments not recommended by the product manufacturer as they may cause hazards.
7. Water and Moisture - Do not use this product near water - for example, near a bath tub, wash bowl, kitchen sink, or laundry tub; in a wet basement; or near a swimming pool; and the like.
8. A product and cart combination should be moved with care. Quick stops, excessive force, and uneven surfaces may cause the product and cart combination to overturn.

9. Ventilation - Slots and openings in the cabinet are provided for ventilation and to ensure reliable operation of the product and to protect it from overheating, and these openings must not be blocked or covered, The openings should never be blocked by placing the product on a bed, sofa, rug, or other similar surface. This product should not be placed in a built - in installation such as a bookcase or rack unless proper ventilation is provided or the manufacturer's instructions have been adhered to.
10. Power Sources - This product should be operated only from the type of power source indicated on the marking label, if you are not sure of the type of power supply to your home. Consult your product dealer or local power company.For products intended to operate from battery power, or other sources, refer to the operating instructions.
11. Grounding or Polarization - This product may be equipped with a polarized alternating-current line plug (a plug having one blade wider than the other). This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet try reversing the plug, If the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.
12. Power - Cord Protection - Power - supply cords should be routed so that they are not likely to be walked on or pinched by items placed upon or against them, paying particular attention to cords at plugs, convenience receptacles, and the point where they exit from the product.



AC Polarized Plug

13. Lightning - For added protection for this product during a lightning storm, or when it is left unattended and unused for long periods of time, unplug it from the wall outlet and disconnect the antenna or cable system. This will prevent damage to the product due to lightning and power - line surges.
14. Power Lines - An outside antenna system should not be located in the vicinity of overhead power lines or other electric light or power circuits, or where it can fall into such power lines or circuits. When installing an outside antenna system, extreme care should be taken to keep from touching such power lines or circuits as contact with them might be fatal.
15. Overloading - Do not overload wall outlets, extension cords, or integral convenience receptacles as this can result in a risk of fire or electric shock.
16. Object and Liquid Entry - Never push objects of any kind into this product through openings as they may touch dangerous voltage points or short - out parts that could result in a fire or electric shock. Never spill liquid of any kind on the product.
17. Servicing - Do not attempt to service this product yourself as opening or removing covers may expose you to dangerous voltage or other hazards. Refer all servicing to qualified service personnel.
18. Damage Requiring Service - Unplug this product from the wall outlet and refer servicing to qualified service personnel under the following conditions;
    a. When the power-supply cord or plug is damaged.
    b. If liquid has been spilled, or objects have fallen into the product.
    c. If the product has been exposed to rain or water.
    d. If the product does not operate normally by following the operating instructions. Adjust only those controls that are covered by the operating instructions as an improper adjustment of other controls may result in damage and will often require extensive work by a qualified technician to restore the product to its normal operation.
    e. If the product has been dropped or damaged in any way.
    f. When the product exhibits a distinct change in performance - this indicates a need for service.
19. Replacement Parts - When replacement parts are required, be sure the service technician has used replacement parts specified by the manufacturer or have the same characteristics as the original part. Unauthorized substitutions may result in fire, electric shock, or other hazards.
20. Safety Check - Upon completion of any service or repairs to this product, ask the service technician to perform safety checks to determine that the product is in proper operating condition.
21. Wall or ceiling Mounting - The product should be mounted to a wall or ceiling only as recommended by the manufacturer.
22. Heat - The product should be situated away from heat sources such as radiators. Heat registers, stoves, or other products (including amplifiers) that produce heat.

WARNING: Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on , the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio TV technician for help.

CD Operation

MP3 CD Operation

1 Press FUNCTION until CD appears on LCD display.

2 Press OPEN/CLOSE to open the CD tray.

3 Place a CD in the CD tray with the label side facing up.

4 Press OPEN/CLOSE again to close the CD tray. The total number of Albums/Folders will be displayed on the upper part of the display. The total number of tracks on the CD will show on the left side of the display.

5 Press PRESET UP or PRESET DOWN to select the desired album/folder.

6 Once the correct album/folder has been selected, press the SKIP+ or the SKIP- to select the desired track within the selected album/folder.

7 Press PLAY/PAUSE to begin playback.

Note: You can switch albums/folders at any time during playback.

Search Play (For MP3 only)

Search by Track name:

1 Press FIND/ESP once , 🔍 will start to flash on on LCD display.

2 Use SKIP + or SKIP- to select the letter (A-Z) that matches the first letter of the track name you would like to find.

3 Once the correct letter is showing, press and hold the SKIP+ or SKIP- button for one second. This allows you to search through all the songs starting with the selected letter.

4 Press SKIP+ or SKIP- to select the track started with the selected letter.

5 Press PLAY/PAUSE to play the selected track.

6 Press STOP to stop playing the CD.

Search by Album name:

1 Press FIND/ESP twice then " ALBUM " and 🔍 will appear on the LCD display.

2 Press the SKIP+ or SKIP- button to select the desired album/folder.

3 Hold the SKIP+ or SKIP- for 1-2 seconds to enter the selected Album , " ALBUM " will appear on the LCD display.

4 Press SKIP+ or SKIP- to select the track in the selected Album.

Note: IF there are files in the root directory, display will show "ROOT" . Hold SKIP+ or SKIP- for 1-2 seconds until "ALBUM" appear on the LCD display. Then search the files in the root directory by pressing SKIP+ or SKIP-.

Welcome

Thank you for purchasing the the Crosley Full Size Tablet Jukebox (CR1205A). Before operating this unit,please read this manual thoroughly and retain it for future reference.

About This Manual

Instructions in this manual describe the control functions of the CR1205A.

Table of Contents

Control Locators
- Unit Controls..... 4
- Lighting remote control..... 5
- Remote Controls..... 6

Getting Started
- Unpacking..... 7
- Power Source..... 7

Basic Operation
- General..... 7
- Radio Operation..... 8

Tablet Operation
- Tablet Operation..... 8

CD Operation
- CD Operation..... 9
- Programming..... 9
- MP3 CD Operation..... 10
- Search Play (For MP3 only)..... 10
- Random and Repeat Play..... 11
- Intro..... 11

General
- Connection Optional Equipment... 11
- Troubleshooting Guide..... 12
- Warranty..... 13

Basic Operation

Radio Operation

1 Press FUNCTION until TUNER appear on the LCD display.

2 Press BAND to select the desired AM/FM tuning band.

3 Press and hold the SKIP+ or SKIP - for one second to automatically tune into to the next available station with a clear reception signal. Repeat this procedure until the desired station is reached.

Programming Stations

1 Press BAND to select the desired AM/FM tuning band

2 Press SKIP+ or SKIP- to tune to the desired frequency.

3 Press PROGRAM , the "PROGRAM" and "01" will start flashing on LCD display.The current preset number will be displayed for selection.

4 If you wish to store the radio station to another preset number, press the PRESET-UP or PRESET-DOWN to select the desired preset number.

5 Press PROGRAM again to store the radio station. Repeat steps 3 to 5 to store other preset radio stations if needed.

6 Once all stations are programmed into memory, use PRESET-UP or PRESET-DOWN to select the programmed presets.
**If a button is not pressed within 5 seconds during programming, the jukebox will automatically exit program mode.
Note: A maximum of 30 radio FM stations for and 10 AM stations can be stored into memory

Tablet Operation

Tablet Operation

1 Press FUNCTION until AUX appears on the LCD display.

2 Pull down the tray and insert the adaptor for AC charger socket then push closed.



3 Slide the tablet frame to the left to remove.



4 Put the tablet into the tray holder and connect the 3.5mm AUX cable into headphone jack.



Note: 1. Keep the table well secured against the bracket while securing the frame.
2. Adjust the tablet volume to "maximum" prior to locking it behind the frame

5 Put the frame back and slide to the right to lock the tablet.



Note: Crosley has enclosed an extra 3mm thickness and 1mm-thickness tablet cushioning pad for users of thinner tablets who need extra cushioning while the tablet is held by the frame.

Control Locators



LIMITED MANUFACTURERS WARRANTY

Crosley Radio, Inc. warrants the product to be free from defects in material and workmanship under normal use for a period of one year from the original date of purchase. This warranty is not transferable. If the product is determined to be defective during the warranty period, the unit will be repaired or replaced at Crosley Radio's sole discretion. This warranty covers manufacturing defects and normal consumer use and does NOT cover damage or failure as a result of abuse, accident, alterations, misuse, neglect, abnormal wear and tear, inadequate maintenance, commercial or unreasonable use, damage caused by power surges, mishandling, accident, acts of God or attempted repair by an unauthorized service agent. Also not covered are cosmetic damages, cords and antennas.

Should this product fail to function in a satisfactory manner, it is best to first contact our technical support team for assistance to ensure it is being operated properly.

Tech Support and Product Questions
CALL TOLL FREE: 1.888.CROSLEY
(1.888.276.7539)

If it is indeed determined that the unit is no longer operational, please contact the retailer from which it was purchased. In many cases, your retailer will be able to provide a replacement unit at no charge within the scope of their return policy. If the retail return period has expired, please contact Crosley Radio directly to participate in the one year protection program.

Crosley 1 Year Warranty Program
CALL TOLL FREE: 1.800.926.7801

You will need to contact our offices M-F 8am-5pm EST to obtain an RA (Return Authorization) Number. You will be instructed to send the unit (at your cost) to our offices in its original packaging (or reasonable substitute to prevent damage.) You will need to clearly mark your RA number on the outside packaging and include the original sales receipt (or a copy) indicating date of purchase, amount paid, and place of purchase. You will also need to include your full name, shipping address and daytime contact number. You will be instructed to include a check or money order for any applicable return shipping and handling fees. A Crosley advisor will confirm the fees associated with your product's shipping size/weight. Returned products will not be shipped to PO Boxes. Crosley Radio will not be responsible for delays or unprocessed claims resulting from a purchaser's failure to provide any or all of the necessary information.

There are no express warranties except as listed above.
The purchaser's bill of sale is the only proof of warranty entitlement.

This warranty gives the purchaser specified legal rights in addition to any rights which may vary from state to state.

In accordance with the "Moss-Magnuson Warranty Act" of July 10, 1975, this is termed a "limited warranty" which in no way compromises Crosley Radio's high standards of quality and workmanship.

WARNING:

TO PREVENT FIRE OR SHOCK HAZARD, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE. DO NOT REMOVE COVER. PILOT LAMPS SOLDERED IN PLACE. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The lighting flash with arrowhead symbol, within an equilateral triangle, is intended to alert user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute risk of electric shock to persons.

CAUTION

RISK OF ELECTRIC SHOCK DO NOT OPEN

CAUTION: TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE COVER (OR BACK). NO USER - SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

The exclamation point within an equilateral triangle is intended to alert user to the presence of important operating and maintenance (servicing) instruction in the literature accompanying the appliance.

"Ventilation not to be impeded."

"Do not expose to moisture or liquids. Do not place objects filled with liquids, such as vases, on the apparatus. "

Specification

FREQUENCY	:	FM 87.5 -108 MHz
		AM 522 - 1710 KHz
POWER SOURCE	:	AC120V~60Hz
ANTENNA	:	EXTERNAL 300 Ohm ANTENNA FOR FM
	:	BUILT-IN FERRITE BAR FOR AM
POWER CONSUMPTION	:	110W
AUDIO POWER OUTPUT	:	18W x 2
SPEAKER OUTPUT	:	18W
SPEAKER	:	6 1/2" Dynamic type x 2
	:	4ohm 40watt
	:	2 1/2" Tweeter type x 2
	:	8ohm 10watt

***DESIGN AND SPECIFICATIONS SUBJECT TO CHANGE WITHOUT NOTICE.**

Random Playing

By selecting Random Mode, the jukebox will randomly select and play songs from the CD loaded in the jukebox. To enable Random Play, follow the steps below.

1 Press RANDOM once to enable random play mode. "RANDOM" will appear on the display.

2 Press RANDOM again to exit random playing mode. "RANDOM" will disappear from the display.

Repeat Playing

1 To repeat one track, select the track you would like to repeat and press PLAY/PAUSE. Press the REPEAT button once. "REPEAT 1" will show on the display and the selected track will play repeatedly.

2 To repeat all songs on the CD, press the REPEAT button the second time. "REPEAT ALL" will show on the display and the CD will start over once finished.

3 If you are listening to an MP3 CD with different albums/folders, you can repeat just the album/folder that is playing by pressing the REPEAT button for a third time.

4 To exit repeat mode, press the REPEAT button for the fourth time."REPEAT" will disappear from the display.
Note: Repeat play is disabled while the random function is being used.

Intro

The Intro feature will play the first 10 seconds of each song on the CD.

1 Once a CD is inserted, press the INTRO button. The first track will start to play.

2 After 10 seconds, the next track will start to play.

3 Once you reach a track that you want to listen to, press the INTRO button again. It will exit the Intro play mode.

Connecting External Speakers

1 This jukebox is equipped with external speaker outputs.

2 The speaker jacks for external speakers are located on the back of the jukebox. Beside the speaker jacks is a switch labeled (int./ext./mix). When using external speakers, this switch must be switched to the ext. or mix position. The ext. position will allow only the external speakers to play. The mix position will allow both the external and internal speakers to play.

3 If you decide not to use the external speakers, be sure the switch is on int. or the internal speakers will not work.

Note: External speakers are not included with the jukebox.

Auxiliary Inputs

Using the Aux Input allows you to hook up additional external audio components and listen to them through your unit. Any component with an audio output such as a Tuner, can be connected by using the correct cables . This unit uses standard RCA cables. Simply plug the red and white connectors on one end of the cable to the red and white RCA In jacks on the back of your unit. The other end of the cable will plug into the Audio Output jack on the external component. For more information on hooking up the external component, see the owner's manual for that component.

Control Locators



CD Operation

CD Operation

1 Press FUNCTION until “A1*D”A1*appears on LCD display.

2 Press OPEN/CLOSE to open the CD tray.

3 Place a CD in the CD drawer with the label side facing up.

4 Press OPEN/CLOSE again to close the CD tray.

5 The total number of tracks and the total play time will show on the display.

6 Press PLAY/PAUSE to begin playback.

7 Press SKIP+ to skip forward to the next track.

8 Press SKIP- to skip backward to the previous track.

9 Press STOP to stop playing the CD.

10 Press PLAY/PAUSE to pause/resume the CD.

Programming

Up to 64 tracks can be programmed for play in any desired sequence.
**The track must be programmed in the stop mode.
**The same track can be programmed more than once.

1 Make sure the CD is stop playing, press the PROGRAM button."00" will begin to flash on the display. After a second, "Memory" and " 000 P - - 01" will show on the display.

2 Press SKIP+ or SKIP- to select the desired track

3 Press PROGRAM to store the selected track. "00" and "P--02" will be shown on the display.

4 Repeat steps 2 and 3 to program additional tracks into memory if needed..

5 Press PLAY/PAUSE to begin playback of the programmed tracks.

Note: a. up to 64 tracks can be programmed
b. If programming songs from MP3 CD's which contains different albums/folder, after pressing PROGRAM, use SKIP+ or SKIP- buttons to select an album/folder and press the PROGRAM button again to enter the album/folder. Once the album/folder is selected, proceed with steps 2-5 above to program tracks into memory.

Control Locators

(2) LIGHTING REMOTE CONTROL



LED LIGHTING CONTROL FUNCTION

To control the LED lighting use the Infra-red Remote Control handset, which has 28 buttons, the function of each button is as in the table below:

Brightness+ (8 in all)	Brightness- (8 in all)	Run/Pause	Dimmer (Press and hold + 5 seconds)
RED (R)	GREEN (G)	BLUE (B)	WHITE (W)
ORANGE	LIGHT GREEN	DARK BLUE	7-colour fast colour change
DARK YELLOW	BLUE	BROWN	STROBE: Colour fade out & fade in -adjustable
YELLOW	LIGHT BLUE	PINK	FADE: 7-colour slow colour change -adjustable
Increase RED	Increase GREEN	Increase BLUE	SMOOTH: 3-colour slow colour change -adjustable
Decrease RED	Decrease GREEN	Decrease BLUE	DIY (adjustment of colour by the user)

Basic Operation

Unpacking

1 Remove packing materials from unit.
Note: Save all packing materials.

2 Remove plastic safety cover from A/C plug.

3 Remove tie from A/C cord

Power Source

1 Unwind the AC POWER CORD at the back of the unit and connect it to a power outlet.

2 Plug A/C cord into appropriate outlet.


AC
Polarized Plug

Note: This product may be equipped with a polaized alternating-current line plug (a plug having one blade wider than the other.) This plug will fit into the power outlet only one way. This is a safety feature. If you are unable to insert the plug fully into the outlet try reversing the plug, if the plug should still fail to fit, contact your electrician to replace your obsolete outlet. Do not defeat the safety purpose of the polarized plug.

3 Install 2 AAA batteries (not included) in remote control.

4 Plug A/C cord into appropriate outlet.

General

1 Make sure the unit is plugged in correctly to an AC outlet.

2 Press the POWER button to turn on the main power. This button should be left pressed in even when the unit is not in use. If the main power is turned off, all preset radio stations will be lost and will have to be reprogrammed.

3 Press the STAND BY button to turn on the unit power. The STAND BY button should be used to turn the unit on or off.

4 Once the Power is turned on, press the FUNCTION button to switch between Tuner/CD/iPod/Aux.

5 While listening to any of the above functions, you may change the tone of the music by pressing the EQ button. Each press of the EQ button will toggle between the following settings:

6 You can also enhance the bass sounds by using the BBS feature. Press the BBS button to turn this feature on.